



CaterSense -02

***GAS SUPPLY CONTROL with
GAS PRESSURE PROVING and / or
INTELLIGENT FLOW DETECTION***

OPERATOR'S MANUAL

Product Overview

The CaterSense system is based on a range of products and ancillary equipment designed to meet the ever changing requirements of the catering industry and associated regulations.

The system comes in four basic modes, you have selected

CaterSense -02 intelligent controller *with Gas pressure proving & / or IFD monitoring*

Contents

- 1.01 How does my CaterSense unit work?
- 1.02 How do I start my CaterSense?
- 1.03 How do I stop my CaterSense?
- 1.04 What do I do if my CaterSense does not operate?
- 1.05 What do I do if my CaterSense goes into an alarm?
- 1.06 Do I have any form of override?
- 1.07 CaterSense facia details
- 1.08 Fault finding and alarm codes

1.01 How does my CaterSense unit work?

Your CaterSense unit is designed to ensure that your kitchen ventilation system is operational and maintaining the design system air flow rates for your kitchen, before your gas supply is enabled to your cooking appliances.

The CaterSense is operated via an easy wipe clean touch pad and LED indicator arrangement as indicated in figure 1.01-1.

1.02 How do I start my CaterSense?

First start your kitchen canopy ventilation system.

Press the START pad on the CaterSense unit. The CaterSense will now carry out a number of system checks and if all checks are clear the gas valve output will switch on after 30 seconds and open the gas valve and supply to your cooking appliances.

If during the start up sequence the CaterSense goes into an alarm mode, please refer to section 1.05 below.

1.03 How do I stop my CaterSense?

Press the STOP pad on the CaterSense unit. The gas valve output will switch off and the gas valve will close, isolating the gas supply to your appliances.

NOTE: Always ensure that all appliances have been switched off and taps closed.

1.04 What do I do if my CaterSense does not operate?

If when you press the START pad your CaterSense does not operate,

- 1 Ensure that your kitchen canopy ventilation system is operational.
- 2 Ensure you have power to the unit; is the power on LED lit?
- 3 If not, have your supply to the unit checked by an electrician.
- 4 If power is on to the unit, refer to section ... of this manual for further instructions.

1.05 What do I do if my CaterSense goes into an alarm?

If when you press the START pad or during its operation, the CaterSense goes into an alarm mode and the audible alarm buzzer sounds.

- 1 Press the ALARM MUTE pad and the audible alarm will stop. (Note: 1.1)
- 2 Identify the LEDs which are flashing and refer to section ... of this manual for further instructions.

1.06 Do I have any form of override?

Following the latest instructions from CORGI **NO** form of operator override can be provided.

1.07 CaterSense facia details



1.08 Fault finding and Alarm codes

In the event that your CaterSense has not operated or has gone into an alarm mode, the following has been designed to help you identify your problem and offer a course of action for you to take.

Fault finding Only to be carried out by a qualified engineer

Fault		Possible cause	Action
No Power On LED	a.	No power to the unit	Check power supply to unit, mains cables and terminals
	b.	Primary transformer fuse "blown"	Remove cover and check if "blown". If yes, check for any signs of a wiring fault and rectify before replacing with a new fuse.
	c.	Secondary transformer fuse "blown"	As b. above
	d.	None of the above	Call for further assistance
Gas valve output LED is red and gas valve is closed	a.	The unit is in an alarm mode	Check for any flashing LEDs and look-up in alarm codes below.
	b.	Start pad has not been pressed	Press STOP pad and press START pad again

	c.	None of the above	Call for further assistance
Gas valve output LED is green and gas valve is closed	a.	No power to gas valve	Check terminals 29/30 to see if 240Vac is present and check cables to gas valve.
	b.	Gas valve not operational	Check if 240Vac is present at gas valve terminals. If yes replace gas valve.
Gas valve open but no gas at appliance	a.	Gas supply has been isolated or is blocked	Check gas supply
	b.	No gas pressure	Check gas supply

Alarm Modes – User actions only

Flashing LED	Cause of alarm		Action
Min Air Flow	Filter / ducting / fan getting clogged		Check and clean
Fan 1 Orange	Low reading on Fan 1 IFD sensor	a.	Check that fan is running
		b.	Check filters and ductwork are clean
		c.	Press STOP pad and press START pad. If system goes into same alarm, call an engineer.
Fan 2 Orange	Low reading on Fan 2 IFD sensor	a.	Check that fan is running
		b.	Check filters and ductwork are clean
		c.	Press STOP pad and press START pad. If system goes into same alarm, call an engineer.
Fire Alarm	Fire Alarm input has been activated		Check and re-set alarm
Remote Knock-off	Remote knock-off has been activated		Check and re-set knock-off
System Condition	CaterSense has monitored a fault		Call an engineer to investigate

Alarm Modes – Action by Engineer only

All of the following actions must only be carried out by a qualified engineer

Flashing LED	Cause of alarm		Action
Fan 1 Orange	Low reading on Fan 1 IFD sensor	a,b,c	See table above
		d.	Check sensor is clean
		e.	Check sensor readings on terminals 1,2,3 & 4
		f.	Check cable to sensor and connections
		g.	Replace if faulty
Fan 2 Orange	Low reading on Fan 2 IFD sensor	a,b,c	See table above
		d.	Check sensor is clean
		e.	Check sensor readings on terminals 5,6,7 & 8
		f.	Check cable to sensor and connections
System Condition	CaterSense has monitored a fault	a.	Check for wiring faults
		b.	Carry-out a re-start
		c.	Carry-out a system reset

Notes: 1.1 *Alarm Mute, if the cause of the alarm is not cleared or the alarm has not been responded to, the audible alarm will re-sound.*

FOR FURTHER TECHNICAL ASSISTANCE, PLEASE CONTACT US BY

Phone: 01782 844688

Fax: 01782 844772

E-mail: info@trentcontrols.com

Web site: www.bs6173.com

- Note:
- i) Ensure that the electrical installation has been installed in accordance with the current edition of the IEE regulations.
 - ii) Ensure that the gas installation has been installed in accordance with the current gas regulations (CORGI).
 - iii) If in doubt, ask! (contact us on or by any of the above).
 - iv) Ensure that the client has been shown how to operate the system and that they have been handed the users guide and override keys.

TRENT PRODUCTS
Trent House
Dewsbury Road
Fenton
Stoke-on-Trent
Tel: 01782 844688 Fax: 01782 844772